BRITISH RAILWAYS–SOUTHERN REGION

VICTORIA CENTRAL

"VC"

WESTINGHOUSE ALL-ELECTRIC FRAME. 3 ILLUMINATED DIAGRAMS. NO CLOSING SWITCH.
BLOCK BELLS & MAGAZINE TRAIN DESCRIBERS TO BATTERSEA PARK JN., CLAPHAM JUNC.B, & STEWARTS LANE.
ALL OVERLAPS ARE INDICATED THUS:— 175 Yᴰᴱᴾ ⅝.
ALL SHUNT SIGNALS ARE FLOOD-LIT.
[T] INDICATES TELEPHONE. ⊙ INDICATES "TRAIN READY TO START" PLUNGER.
□ INDICATES "OFF" INDICATORS, WORKING WITH STARTING SIGNALS, FOR INFORMATION TO STATION STAFF.
SPARE TRACK CIRCUIT LETTERS. AD. BC. FL. EU.

◊ GROUND FRAME NUMBERS

LEVER 21 LOCKS POINTS 22 NORMAL AND RELEASES SIGNALS 5 & 6

CONTROLLED BY 27

BATTERSEA PARK JUNCTION

SIDING Nº 2

SIDING Nº 1

CARRIAGE ROAD

SHEWS 'CR' OR 'T'

SHEWS 'CR' OR 'SD'

CONTROLLED BY HC.16 WHEN 4 NOR.

UP THRO

DOWN THRO

UP LOCAL

DOWN LOCAL

CARRIAGE SIDINGS

WORKED BY ◊ WHEN 22 NORMAL

CONTROLLED BY ◊ WHEN 22 REV.

REL. 21

GROUND FRAME

SHUNTING INDICATOR

SIGNAL BOX

CONTROLLED BY ◊ FOR ENGINE SIDING Nº 2

CONTROLLED BY ◊ Nº 3 ENGINE SIDINGS

DOCK Nº 1

DOCK Nº 2

MIDDLE D

MIDDLE D (SIDING)

MIDDLE C

MIDDLE B

MIDDLE A

SHEWS L OR T FOR MAIN SIGNAL AND D OR S FOR SHUNT SIGNAL

300 Yᴰᴱᴾ TO SAND DRAG

PLATFORM INTERMEDIATE SIGNALS

BRIDGE DEPARTS 200/201

ESCAPE 202

EBURY BRIDGE

ELIZABETH BRIDGE

ECCLESTON BRIDGE

✻ MOVABLE DIAMONDS

DOWN LOCAL WARNING LIGHTS ON EACH SIDE OF POST 2 ON BUTTRESS BATTERSEA PARK SIDE OF EBURY BRIDGE.

DOWN LOCAL WARNING LIGHTS CONTROLLED BY POINTS Nº 142 REVERSED

SIGNALS Nº 143, 148 CONTROLLED BY DOWN LOCAL WARNING LIGHTS WHEN POINTS Nº 142 REVERSED

Nº 191 & 192 SIGNALS WORK AUTOMATICALLY WHEN LEVERS REVERSED

NO LIGHT WHEN ARM ON
YELLOW WHEN ARM OFF & SIGNAL AHEAD RED
GREEN " " " YELLOW, 2 YELLOW OR GREEN

VISUAL & AUDIBLE INDICATION IN STEWARTS LANE SIGNAL BOX WHEN VC 145 CLEAR

YELLOW WHEN LEVER 190 REV.
GREEN WHEN LEVERS 190 REV. & 127 REV. AND ASM [127] OFF

CONTROLLED BY HC 31

[90] VICTORIA EASTERN CONTROL WHEN ROUTE SET FOR UP RELIEF

REL BY VICTORIA EASTERN [147]

721 CONTROL ON VICTORIA EASTERN [128] WHEN ROUTE SET FOR DOWN LOCAL

222 CONTROL ON VICTORIA EASTERN PLATFORM TO DOWN LOCAL STARTERS

| LEVER Nº | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | 112 | 113 |
|---|---|---